




Instructions to determine the correct Riser-TEQ pattern:

- Step 1)** Print this document to produce a standard A4 letter head page (NOTE: set size to 100% and 'landscape').
- Step 2)** Fold at the  dotted lines, and place the pattern against the escalator tread riser to compare patterns.
- Step 3)** Select the pattern that fits from one of the three shown below (No. i23, t23 or u23).

Pad Pattern - i23 (Order EscaTEQ P/N: 801048 - 10 pads/box)



Pad Pattern - t23 (Order EscaTEQ P/N: 801049 - 10 pads/box)



Pad Pattern - u23 (Order EscaTEQ P/N: 801050 - 10 pads/box)



Riser-TEQTM

maintenance cleaning system for escalator risers

Restorative Deep Cleaning:

- 1) Turn off the escalator.
- 2) Spray 1:10 diluted Clean-TEQ Cleaning Solution on the vertical risers (about 5 risers at a time, a very light mist is all that's required).
- 3) Wait 5 minutes, allowing Clean-TEQ time to penetrate into the dirt.
- 4) Spray additional Clean-TEQ on the Riser Pad as required and start cleaning, using an up and down motion with the Riser Pad and tool.

Maintenance Cleaning:

- 1) Turn off the escalator.
- 2) Spray 1:10 diluted Clean-TEQ Solution on the Riser Pad and begin cleaning. Clean the risers using an up and down motion with the Riser Pad.

Notes:

- If you want to remove grease or oil, try a dry Riser-TEQ Pad (without Clean-TEQ) first.
- If necessary spray additional Clean-TEQ on stubborn stains and spots.
- Rinse dirty Riser-TEQ pads with a strong stream of water and allow to drip dry to reuse.